






INDIANAPOLIS I-14



Narzędzia potrzebne do montażu




UWAGA !!
MONTOWANIE USZKODZONYCH
ELEMENTÓW POWODUJE UTRATĘ
GWARANCJI




nr	D[mm]	S[mm]	G[mm]	Ilość
1	480	422	48	1
2	900	582	48	1
3	886	563	16	1
4	478	403	16	1
5	1870	403	16	1
6	530	80	16	1
7	545	80	16	1
8	1870	563	16	1
9	1773	420	16	1
10	1773	420	16	1
11	868	410	16	1
12	868	80	16	1
13			16	4
14	1800	445	2,5	2
15	1800	345	2,5	2
16	1780	395	16	1
17	1780	395	16	1
18	1870	80	16	1
19	1870	80	16	1

W przypadku reklamacji proszę o podanie numeru pakowacza znajdującego się na kartonie



J - 2 St.




H - 2 St.



F - 5 St.




R - 1 St.



K - 21 St.



B2 - 6 St.




A - 11 St.



O - 8 St.




U - 2 St.




Y - 2 St.




S - 20 St.




C1 - 4 St.




D1 - 4 St.



N - 4 St.
M4 x 25 mm



C2 - 4 St.



D2 - 4 St.




E - 80 St.



B1 - 24 St.



G - 38 St.
3,5 x 16 mm




Z - 1 St.




L - 33 St.



I




II




III





V



VI

